

# NGP Advanced NGP Advanced Extra NGP Advanced Extra DP4

Installation Guide



# Contents

<b>Introduction</b>	<b>3</b>	Configuration menu		<b>Interconnection monitoring</b>	<b>45</b>
Specifications	5	programming	18	Wiring for interconnection	
Safety notes	7	Button configuration	19	monitoring	46
<b>Mounting and wiring</b>	<b>8</b>	<b>Main menu display</b>	<b>20</b>	What happens when pins	
Removal of cover	9	Inputs	22	are configured and wired	
Mounting	9	Outputs	25	in this way	47
Connection terminals	10	Network	27	Example configuration	
Power connections	10	Serial connection panel type	31	and wiring for connection to	
Alarm inputs	10	Diagnostics	33	fire panel with interconnection	
Outputs	11	Offline reboot screen	34	monitoring	47
Serial data connections	11	Restore defaults	34	Roaming SIMs	48
Dial capture	11	<b>Web server</b>	<b>35</b>	Panel upload Download and	
Ethernet connection	11	Main status display	37	Enhanced format signalling	
<b>Programming</b>	<b>12</b>	Status	37	(SIA/CID)	48
Unit initialisation	13	System messages	37	Dial Capture	48
Status display	13	Pins	38	Serial panel connections	48
Signal strength	14	Events	38	Connection advice	49
Guide to signal strength	14	Users	39	Alarm list	50
Path status	14	Settings	39	<b>Personal Data</b>	<b>52</b>
Pin inputs	15	Logout	44	<b>Disposal</b>	<b>53</b>
Default outputs	15	Web portal and AddSecure app	44	<b>Glossary</b>	<b>54</b>
<b>Configuration</b>	<b>17</b>	Compliance with the user access		<b>Approvals</b>	<b>55</b>
Pin Learn	18	level requirements of EN 50136	44	<b>Appendix</b>	<b>59</b>



# Introduction

# Introduction

## Product description

NGP Advanced, NGP Advanced Extra and NGP Advanced Extra DP4 are dual path alarm signalling units for transmitting alarm signals from a customer's alarm panel, via the AddSecure network, to an Alarm Receiving Centre (ARC) using pass-through mode of operation. NGP Advanced, NGP Advanced Extra and NGP Advanced Extra DP4 are IP primary path with dual SIM 4G/2G mobile technology as the backup path. The units are designed and certified for use in both Security and Fire systems.

The unit communicates via the AddSecure Network and a valid TA (Terminal adapter) account must exist for the unit to communicate. The TA account will have been populated with the serial number of the unit. Once connected to the platform the unit uses a poll and response check to determine path status. When the primary path fails the secondary path will take up the polling and reporting parameters of the primary path.

Individual path fails are transmitted over the remaining path. Dual path failure is platform generated.

The unit has 16 general purpose alarm inputs, and 3 outputs, making it suitable for connection to most common alarm panels. The unit is supplied already fitted with two AddSecure enabled SIM cards, one an EE UK fixed SIM and a UK roaming SIM. Both enabled for 4G/2G connectivity.




Figure 1 – NGP Advanced, NGP Advanced Extra and NGP Advanced Extra DP4 unit (not to scale)

# Specifications

	NGP Advanced	NGP Advanced Extra	NGP Advanced Extra DP4
<b>Primary path fail reporting</b>	30 mins	180 secs	90 secs
<b>Secondary path fail reporting</b>	5 hours	60 mins	60 mins
<b>Both paths fail concurrent</b>	60 mins	6 mins	3 mins
<b>Catastrophic failure (both paths together)</b>	31 mins	4 mins	3 mins
<b>Alarm Transmission category EN Standards / PD6669 (UK)</b>	DP2	DP3	DP4
<b>PD6669, EN50131 (2017) Grade</b>	3/2	3	4
<b>Grade option (Table 10 EN50131-1 2020)</b>	3C, 2F	3E	4C
<b>Previous grade (Pre June 1st 2019)</b>	3	4	4
<b>Environmental class</b>	II	II	II
<b>Certified for use in fire system category</b>	P	P	L&P
<b>Information and Substitution security</b>	AES256	AES256	AES256
<b>Size</b>	95mm x 67mm x 17mm		
<b>Weight</b>	85g		
<b>Power</b>	9V – 30V		

## INTRODUCTION

Current	Average Normal Operation	Average Max loading (inc relays and dial capture operated)
NGP Advanced IP/4G @12V	98mA	185mA
NGP Advanced Extra IP/4G @12V	104mA	214mA
NGP Advanced IP/4G @24V	45mA	100mA
NGP Advanced Extra IP/4G @24V	45mA	100mA

<b>Alarm inputs</b>	16 General purpose inputs 1–16. (-0.5V – 30V)	
<b>Alarm threshold</b>	High >2V, and Low <1.3V	
<b>Outputs</b>	3 x Relay NO C NC (COMMS, FUNC, FIRE). Max rating 1A @ 30V DC	
<b>RS232 port</b>	Remote panel access (UDL) and signalling to some intruder panel types	
<b>RS485 port</b>	Remote panel access (UDL) and signalling to some intruder panel types	
<b>Configuration</b>	Using on board configuration buttons, web portal or app	
<b>Processor</b>	STM32	
<b>Wireless module</b>	ELS61	ELS62
<b>GSM/GPRS/EDGE</b>	Dual band 900/1800MHz, maximum transmit power +34.5dBm	850 (BdV) / 900 (BdVIII) / 1800(BdIII) / 1900 (BdII). Maximum power transmit +35.5dBm
<b>LTE</b>	Penta-Band 700 (Bd28)/800 (Bd20)/900 (Bd8)/1800 (Bd3)/2100 MHz (Bd1), maximum transmit power	2100(Bd1) / 1900(Bd2) / 1800(Bd3) / 2100(Bd4) / 850(Bd5) / 2600(Bd7) / 900(Bd8) / 800(Bd20) / 700(Bd28) / TDD2600(Bd38) / TDD2300(Bd40) / TDD2500(Bd41)2 / 2100(Bd66). Maximum power transmit +25.7dBm
<b>Operating range</b>	-10 to +50 degrees Celsius, average 90% non condensing humidity	

# Safety notes

## Work area safety

- Keep work area clean, well lit and free of obstacles.
- Keep floor and walkways clear of cables and materials to avoid trip hazards.
- Keep children and bystanders away while performing installation and maintenance work.
- Remove any left over materials when finished and keep all items away from children and pets.

## Personal safety

- Stay alert and attentive. A moment of inattention may result in personal injury.
- Do not perform installation or maintenance work when tired or under the influence of medication, drugs or alcohol.
- Upon commencing work on security system enclosures and components, ensure the item is securely fixed to

the wall and that no components or contents such as the battery can fall and cause personal injury.

## Electrical safety

- Exercise care when working inside security system enclosures:
- Metallic tools, fingers, body parts or jewellery coming into contact with mains wiring and terminals may cause electric shock.
- Metallic tools or jewellery coming into contact with battery terminals may cause sparks, personal injury or create a fire risk.
- Exercise care when drilling into, or inserting fasteners into walls. Pipes and wiring may be present in the wall and contact with tools or fasteners may provide risk of electric shock, damage to premises services, or create a fire risk. Locate wiring, pipes and services first to avoid accidents.

### WARNING!

Read all safety warnings and instructions. Failure to heed warnings and follow instructions may result in electric shock, fire risk and/or personal injury.





# Mounting and wiring



### Connection terminals

The screw terminals for the alarm inputs are suitable for use with a standard 3mm blade terminal screwdriver.

### Power connections

Power to the unit is via 2 screw terminals at the centre, with positive to the right nearest Pin 9.

The supply voltage range is 9V to 30V. The unit is designed to be connected to the auxiliary power output on an associated alarm panel, or separate powered enclosure. For use with intruder alarm panels the power supply must meet the requirements of EN 50131-6.

For use with Fire alarm panels the power supply must meet the requirements of EN 54-4 and the unit must be mounted in the same enclosure as the power supply from which it derives its power. Ensure the power source is sufficient to power all devices connected. *See the power requirements in the specification section for more information.*




The account at the Alarm Receiving Centre (ARC) should be put 'on test' before power up, as signals will be sent following initialisation.

### Alarm inputs

The unit has 16 alarm inputs which are presented on screw terminals along the bottom of the unit. These are labelled as Pin 1-8 and 9-16.

By default the 16 alarm inputs require a positive condition to be presented to send an alarm (Default = Positive applied). This can be changed using the Pin Learn button or through the configuration menu. *See later section on Configuration.*



Input (Pin)	Use
1	Fire alarm (When programmed Fire NAK and ACK outputs operate in conjunction with Pin 1)
2	Fire Fault or Hold up alarm
3	Intruder alarm
4	Open / Close (Set / Unset) (FUNC output can be set up as RPS in conjunction with Pin 4)
5-10	General alarm
11	ATS input (BSIA F175 mode) (Can be reprogrammed as a normal alarm pin)
13	AC Fail alarm (has a 7 minute delay which can be altered in programming)
14-16	General alarm

Figure 3 – Alarm input allocations. Functions must be agreed with your ARC

## Outputs

Three relay outputs are provided on screw terminals at the top of the unit.

Output 1 is COMMS, Output 2 is FUNC, and Output 3 is FIRE.

For fire alarm installations the indication of 'acknowledgement of fire alarm' and 'SPT fault' messages must be provided by the fire panel into which the SPT is mounted. System fault indications which are notified by the line fault output (Output 1) must be latched by the fire panel as required by EN 54-21.

See the further sections on outputs for a full explanation.



## Serial data connections

The serial data connection labelled TX, RX, B and A is configurable for RS485 or RS232 connection, depending on the panel.

This is done in the configuration menu. These ports allow serial alarm panel connection.

See the *Panel Upload-Download section*.



## Dial capture

The Dial Capture (Dial Cap) terminals enable interfacing with an alarm panel's digital communicator. The alarm panel can then send SIA, CID or Fast Format messages through the unit to the Alarm Receiving Centre.

Dial Capture can also be used for upload/download UDL allowing remote access with some types of alarm panel.



## Ethernet connection

The Ethernet port needs to be connected to a suitable Ethernet network using CAT5 cable. For most IP installations, a standard Ethernet patch cable can be used. The unit monitors the valid presence of a 10/100 Mbit Ethernet link.

## Aerial connection

Connect the supplied aerial to the MMCX connector on the top right of the unit. The aerial should be placed in a vertical position that receives the best wireless coverage. Carry out a survey to establish the best location. If necessary, a selection of high gain and extension aerials can be purchased via your ARC.



# Programming

# Programming

## Unit initialisation

The unit will immediately attempt to connect to the AddSecure platform over the configured paths. The unit will typically complete path establishment in the following times from power up.

<b>IP</b>	120s
<b>4G/2G</b>	120s

Figure 4 – Time to commission paths after unit power up

## Status display

The unit clearly displays its status on the OLED. In its normal working state, the unit will cycle its display.

<p><b>Path: Ethernet Registered</b></p> <p>IP Path and if registered with the platform.</p>	<p>Mobile Path and if registered with the platform.</p>
<p><b>Mobile1 Strength 4G [■ ■] [-103]</b></p> <p>Signal strength – network type (4G or 2G) received wireless signal strength in dBm and signal strength indicator bars. Two bars or more is the recommended signal level required.</p>	<p><b>Mobile1 Operator EE</b></p> <p>Shows the mobile network that the device is connected to.</p>
<p><b>Alarms GPI Alarm 3</b></p> <p>Pin status – any outstanding alarm pins will be shown. If no pins are in the alarm state, then pin status will not be shown..</p>	<p><b>Alarms Battery Low Battery</b></p> <p>The unit may also show Low Battery if the supply voltage is below the supply threshold.</p>

<p><b>Service Grade Redcare DP3</b></p> <p>Service Grade – shows the EN Performance category. DP2 for NGP Advanced, DP3 for NGP Advanced Extra and DP4 for NGP Advanced Extra DP4.</p>
--

The performance category can only be determined by the unit while in contact with the platform. The unit will not show the performance category until at least one path is registered and the profile can be retrieved from the platform.

## Signal strength

### Signal strength that is:

- On 2G below -90dBm = X will be displayed
- On 2G between -90 and -85, 1 bar will be displayed
- On 2G between -85 and -80, 2 bars will be displayed
- On 2G between -80 and -75, 3 bars will be displayed
- On 2G above -75dBm, 4 bars will be displayed

### Signal strength that is:

- On 4G below -120dBm = X will be displayed
- On 4G between -120 and -110, 1 bars will be displayed
- On 4G between -110 and -100, 2 bars will be displayed
- On 4G between -100 and -90, 3 bars will be displayed
- On 4G above -90dBm, 4 bars will be displayed

X or 1 bar – try to improve the signal by moving the unit, aerial or using an extension or high gain aerial – via your ARC.

## Guide to signal strength



Figure 5 – Signal strength chart

## Path status

The state of the communication paths is indicated by the OLED display, both the IP and mobile path have the following possible path status:

- **Up No Reg** – path is up but not registered with the platform.
- **Registered** – has contacted the platform and successfully registered.
- **Alarm/ACK** – Alarm is being transmitted and awaiting acknowledgement.
- **Down** – the path has lost connectivity to the platform and is trying to reconnect.

**NOTE:** When fully commissioned over both paths, then both paths should be registered.



Figure 6 – Typical display cycling on a fully commissioned unit with a good signal strength and Pin 4 in the alarm or open state

### Pin inputs

Of the 16 alarm pin inputs, all behave as general purposes inputs with the following exceptions:

- Pin 1 must be used for Fire alarm when ACK NAK outputs are used for Fire panels. The signalling unit, when configured, provides an acknowledge and not acknowledged indication via use of outputs 2 (FUNC) and 3 (FIRE).
- Pin 4 can have an RPS output or a Keyswitch associated with it. (See *output 2 RPS or a Keyswitch (N/A for FIRE config)*).
- Pin 11 acts as an ATS input as per the requirements of the BSIA form 175 document. This applies only when output 1 is set to BSIA mode. N/A when configured for Fire.
- Pin 13 acts as an AC fail input and therefore has a default 7 minute delay before a Pin 13 alarm is transmitted. It also has a 7 minute delay before a reset is sent. On presenting an alarm condition to Pin 13, the unit's display will show the alarm immediately but 7 minutes of constant alarm condition needs to elapse before transmission.

Similarly, restoring Pin 13 will immediately remove Pin 13 from the display, but 7 minutes of constant restore condition needs to elapse before transmission of Pin 13 restore.

- The 7 minute time delay can be configured through the web portal or app by typing a new value up to 99 (mins) in the 'Mains Fail delay' field. If the 'Mains Fail delay' is set to 0, then Pin 13 can be used as a general purpose alarm input. (Subject to ARC acceptance).
- Pins 1 – 16 can be set up for End of Line and Dual End of Line interconnection monitoring see descriptions on end of line monitoring.

### Default outputs

#### Output 1 (COMMS)

Output 1 acts as the Communications fail output.

The mode of operation can be selected through the configuration menu (see *Configuration section*).

##### 1. BSIA form 175 output

This allows the alarm panel to interrogate path faults as single path or dual path. By default the relay output will switch, following either path fail, once the relevant timer has expired.


If ATS input (Pin 11) is toggled during the fail period, e.g. (panel

interrogation) then Output 1 will either switch back to indicate a single path failure, or remain operated to indicate a dual path failure.

The unit also supports inverted mode BSIA175 operation by learning Pin 11 to be positive removed.

2. Single path fault. Will operate when either path is in fault.
3. Dual path fault. The relay will operate when both the IP and Mobile path are in fault.
4. IP Path fault. To be used in conjunction with Output 2 for the Mobile path.

Condition	Output 1	Relay Terminal
Power Off	Output 1	C <-> NC
Path Up and Registered	Output 1	C <-> NO
Path fail	Output 1	C <-> NC



Relay status with path fail in operation

## Output 2 (FUNC)

Output 2 has a number of configuration options:

### 1. Dual path fault:

Will operate when both paths are in fault.

### 2. User control output:

This can be switched on and off from the web portal or the app.

### 3. Mobile path fault output:

In this case Output 1 is set as the IP path fault output, and Output 2 as the Mobile path fault output.

### 4. RPS output for Pin 4:

The output will operate when input Pin 4 is triggered. It will return to normal when an acknowledge signal is returned from the ARC. The output has a minimum operation time of 1s. When the acknowledgement is received in less than 1 second after Pin 4 is triggered then the output will remain operational for 1s.

### 5. Fire NAK output:

When configured in this way, Output 2 will activate after a Pin 1 alarm is sent and no acknowledgement from the platform is received for 80s. By default Output 2 is set to Dual path fault.

### 6. Keyswitch:

Set or unset the alarm system in conjunction with the AddSecure app.

## The NAK and ACK relay operate in the following mode:

Condition	Fire ACK	Relay Terminal
Power Off	Output 3	C <-> NC
Not in ACK (idle)	Output 3	C <-> NO
ACK	Output 3	C <-> NC
	Fire ACK	Relay Terminal
Power Off	Output 2	C <-> NC
Not in ACK (idle)	Output 2	C <-> NO
NAK (no ACK for 80 seconds)	Output 2	C <-> NC

## Output 3 (FIRE)

### 1. User operated:

The default setting for output 3. This can be operated by the web portal or the app.

### 2. Fire ACK output:

When configured in this way, output 3 will activate when an acknowledgment to a Pin 1 alarm is received. It will de-activate when Pin 1 resets.

### 3. Keyswitch:

Set or unset the alarm system in conjunction with the AddSecure App.

## Keyswitch Mode (Visible when output 2 or 3 set to Keyswitch)

- **Momentary** – momentary pulse to allow set and unset of alarm panel with customer app.
- **Latched** – Latched output option to allow set and unset of panel with customer app. Used in conjunction when setting output 2 as Keyswitch.

### Default Outputs 1, 2 and 3:

- **Output 1** is set to BSIA 175 and will operate if either path is in fault.
- **Output 2** is set to Dual path fault. This allows a choice for simple installations for PD6669 without reprogramming.
- **Output 3** is set to User operated.

### Fire output settings:

To ensure that the NGP Advanced, NGP Advanced Extra and NGP Advanced Extra DP4 units can inform the fire alarm panel of status as per the requirements of EN 54, the outputs need to be configured as follows:

#### Output 1:

**COMMS – Single Path fail** – will operate when either signalling path fails.

#### Output 2:

**FUNC – Fire NAK** – will operate after a Pin 1 alarm is sent and no acknowledgement from the Alarm Receiving Centre (ARC) is received for 80s.

#### Output 3:

**FIRE – Fire ACK** – will operate when an acknowledgment to a Pin 1 alarm is received from the ARC. It will return to normal when Pin 1 is reset.

Output 1 will be operated in the normal state. This ensures that, in the unlikely event of a total failure of the unit, the fire panel will still detect a state change on its fault input.



# Configuration

# Configuration

## Pin Learn

For speed of installation a single button press Pin Learn is available. All pins to be used should be wired in and all the pins should be in the non alarm state. No tampers should be active (if wired in) and Pin 4 (open/close) should represent the system being set/closed.

When ready, press and hold the down arrow for 3s. 'Notice – Done!' is displayed when finished. This has completed the Pin Learn. There is also an option to learn the pins within the configuration menu.

## Configuration menu programming

The unit is supplied pre-configured with factory default values. For most installations no changes to the configuration are required.

Press & Hold for Pin Learn



Notice – Done!

The unit can either be configured by using the on-board configuration menu driven by the buttons, or through the installer app or web portal. Some configurations are only available through the app or web portal. For use of the app or web portal remotely, written authorisation is required from a Level 2 user.


A minority of sites may require minimal configuration changes at installation, and most of these will be achievable through the button configuration, e.g:

- Change the individual pin status.
- Enable Dual End of Line for interconnection monitoring.
- Change the IP mode from Ethernet to wi-fi.
- Change from dynamic to static IP addressing, and allocate a static IP address/subnet/gateway address.



### Button configuration

Enter the button configuration mode by holding down the centre configuration button (Enter) for three seconds.



The unit will then display 'Configuration'.

#### Configuration



Press the Enter button again and the display will show the first menu option.

#### Inputs



Pressing the Enter button on any menu item will enter the sub-menu and take you into edit mode. This will allow the function to be changed. The structure of the sub-menu depends on the menu item.

When in the main menu, each press of will step to the next menu item down.

Use to step back up and eventually return to the top of the menu. The full main menu options are shown in Fig. 7.

### Output Type 1\* Single Path Fault

You know you are in edit mode and that changes can be made by a \* next to the menu title.

### Notice - Saved!

Typically, many menu items simply have two options, use the down and up arrow to switch between the two. Press and hold the Enter button to save changes. Display will show 'Notice - Saved!'

Some menu items have more options. For example, Output 2 has four options to set the comms fault output type. On such menus, press the Enter button to enter the sub-menu, then use the down and up arrows to increment through the options with each press. Holding the Enter button for 5s will save changes. Display will show 'Notice - Saved!'

Some more complex menu items use the Enter button to also step through additional items in the sub-menu. E.g. Network IP addresses to be input.

Edit mode can be exited at any time, without saving changes, by pressing for 5s. This will return you to the sub-menu that you were making changes in.

The configuration menu can be exited at any time without saving any changes by pressing for 5s. This will take you back to the scrolling status display.



# Main menu display

# Main menu display




Figure 7 – Button configuration main menu options

## Inputs


### Pin Learn

The polarity of pins can be learnt by pressing and holding the down arrow for 5s.


The display will show 'Notice – Done!'.


Pin Learn can also be carried out through the configuration menu.

*Example – to learn the pin polarity in the configuration menu:*



- Access the button configuration menu by holding the Enter button. Configuration is displayed.
- Press the Enter button again.
- The display now shows 'Pin Learn'.
- Press and hold the Enter button – the display shows 'Notice – Done!'.


Edit mode can be exited at any time, without saving changes, by pressing  for 5s. This will return you to the sub-menu that you were making changes in.

The configuration menu can be exited at any time without saving any changes by pressing  for 5s. This will take you back to the scrolling status display.


### Input Sense


The polarity of the pins can manually be configured by the installer. This is in addition to the Pin Learn function described earlier.

**Example – to configure Pin 4 to be positive removed:**



- Access the configuration menu by holding Enter button for 3 seconds, press the Enter button again, the display will show 'Pin Learn'. Press the down arrow. The display will show 'Input Sense'. Press the Enter button again to enter Input Sense. Pin 1 and status will be shown.
- Use the down arrow to step through the pins. Once the desired pin is reached press the Enter button. \* will be displayed. Use down or up arrow to change to High or Low.
- High (positive applied) or Low (positive removed).
- Once selected hold the Enter button down till 'Notice – Saved!' is displayed.
- Then it will return to the position in the menu for you to select another pin or use the down arrow to step through all pins to get to the Back option.

Edit mode can be exited at any time, without saving changes, by pressing  for 5s. This will return you to the sub-menu that you were making changes in.


The configuration menu can be exited at any time without saving any changes by pressing  for 5s. This will take you back to the scrolling status display.

### Inputs EOL

The alarm inputs (pins) can be set to the following modes:

- None – (Alarm and Restore)
- EOL (Single End of Line mode) – (Alarm, Restore and Cut)
- DEOL (Dual End of Line mode) – (Alarm, Restore, Cut and Short)

**Example – configure Pin 1 for DEOL:**



This allows the unit to monitor the wiring to the alarm panel contacts.

- Access the configuration menu by holding the Enter button for 3s. Press the Enter button again, the display will show 'Pin Learn'. Press the down arrow twice. The display will show 'Inputs EOL'. Press the Enter button again to enter Input EOL. 'EOL 1 = None' will be shown.
- Use the down arrow to step through the pins. Once the desired pin is reached press the Enter button. \* will be displayed. Use down or up arrow to change to None, EOL or DEOL.
- Once selected hold the Enter button down till 'Notice – Saved!' is displayed.
- Then it will return to the same position in the menu for you to select another pin or use the down arrow to step through all pins to get to the Back option.

Edit mode can be exited at any time, without saving changes, by pressing for 5s. This will return you to the sub-menu that you were making changes in.

The configuration menu can be exited at any time without saving any changes by pressing for 5s. This will take you back to the scrolling status display.

## Outputs

The three relay outputs can be configured as follows:

### 1. Output type 1 (COMMS):

- **BSIA 175 Mode** – operates when either path is in fault but in conjunction with Pin 11 ATS allows the panel to interrogate the device to determine a single or dual path fault (default).
- **Single path fault** – operates when either path is in fault.
- **Dual path fault** – operates when both paths are in fault.
- **IP path fault** – operates when the IP path is in fault.

### 2. Output type 2 (FUNC):

- **Dual path fault** – operates when both paths are in fault (default).
- **User** – allow the relay to be operated remotely via the app or portal (default).
- **Mobile path fault** – operates when the mobile path is in fault.
- **RPS** – return path signal operates in conjunction with Pin 4.
- **Fire NAK** – Fire pin not acknowledged. Operates in conjunction with Pin 1.
- **Keyswitch** – Set and unset the alarm system in conjunction with the AddSecure app.

### 3. Output type 3 (FIRE):


- **User** – allow the relay to be operated remotely via the app or portal.
- **Fire ACK** – Fire pin acknowledged. Operates in conjunction with Pin 1 (default).

• **Keyswitch** – Set and unset the alarm system in conjunction with the AddSecure app.

#### Keyswitch mode:

- **Momentary** – allow the FUNC relay, when set to Keyswitch, to be operated remotely via the app or portal by one pulse of the relay (default).
- **Latched** – allow the FUNC relay, when set to Keyswitch, to be operated remotely via the app or portal by latching the relay.

**Example – configure Output 1 (COMMS) for a single path fault:**



- Access the configuration menu by holding Enter button for 3s. Press the Enter button again, the display will show 'Pin Learn'. Press the down arrow until 'Output Type' is displayed. Press the Enter button again. The display will show the default setting for Output type 1. Use the down arrow to step through the Output types. Once the desired output is reached press the Enter button. \* will be displayed. Use down or up arrow to change to the required configuration for that output.
- Once selected hold the Enter button down till 'Notice – Saved!' is displayed.
- Then it will return to the same position in the menu for you to select another output or use the down arrow to step through all outputs to get to the Back option.

Edit mode for that part of the menu can be exited at any time, without saving changes, by pressing for 5s. This will return you to the sub-menu that you were making changes in.

The configuration menu can be exited at any time without saving any changes by pressing for 5s. This will take you back to the scrolling status display.

## Network


The programming options under the network sub-menu are:



- **DSL/FTTP mode** – Allows the unit to be changed between dynamic (DHCP client) or Static mode. Default setting is DHCP. The Ethernet port will attempt to obtain an IP address from a DHCP server on the LAN.
- **IP address** – shows current IP address but can also be configured for a static IP address.
- **Subnet mask address** – shows current subnet address but can also be configured for a customer's subnet address.
- **Gateway address** – shows current gateway address but can also be configured for a customer's gateway address.
- **DNS Address 1** – can be configured to use specific DNS servers.
- **DNS Address 2** – can be configured to use specific DNS servers.
- **Tunnel Port** – Port 443 is default but there is an option to use 10443.
- **Web passcode** – used in conjunction with installer and customer apps.

## MAIN MENU DISPLAY

When DHCP is set to disabled this then sets the unit in Static IP addressing mode.


**Example – to change from DHCP to Static mode:**






- Access the configuration menu by holding the Enter button for 3s. Press the Enter button again, the display will show 'Pin Learn'. Press the down arrow until 'Network' is displayed. Press the Enter button again. 'DSL/FTTP Mode' is displayed. Press the Enter button. \* will be displayed. Use up arrow to switch to Static IP addressing.
  - Once selected hold the Enter button down till 'Notice - Saved!' is displayed.
- Edit mode for that part of the menu can be exited at any time, without saving changes, by pressing  for 5s. This will return you to the sub-menu that you were making changes in.
- The configuration menu can be exited at any time without saving any changes by pressing  for 5s. This will take you back to the scrolling status display.


### Setting a static IP address, netmask and gateway address

If the unit is to be connected to a LAN that requires the unit to have a static IP address (e.g. no DHCP server on the LAN) then this can be configured as follows after setting DHCP to Disabled.

Then use  to step to subnet address and use the same process as above to set the subnet address.




Then use  to step to gateway address, and use the same process as above to set the subnet address.




Note that IP addresses are made up of 12 digits in 4 batches of 3, separated by dots. When the addresses are entered through the buttons they must be put in as 12 digit numbers, with zeros used to the left of each batch where necessary to pad out the addresses, e.g.:

- IP Address = 192.168.001.056
- Subnet mask = 255.255.255.015
- Gateway = 192.168.001.254

The full address will be shown on the display for each of the above.

Edit mode for that part of the menu can be exited at any time, without saving changes, by pressing  for 5s. This will return you to the sub-menu that you were making changes in.


The configuration menu can be exited at any time without saving any changes by pressing  for 5s. This will take you back to the scrolling status display.

## Tunnel port

You can select an alternative tunnel port by accessing the Tunnel Port menu under Network:

- 443 (default)
- 10443

### Example – changing the unit to use Port 10443



When used in IP mode, the unit will attempt to establish a connection to the AddSecure servers by signalling on IP Port 443. For most LANs this will function correctly, but on some NGP Advanced LAN configurations the network manager may not allow outgoing access on port 443 but 10443 may have outgoing access. Where this is the case then the unit can be configured to use the alternative port 10443. The AddSecure servers are set to accept both ports and so no changes are required other than on the unit's configuration.

- Access the configuration menu by holding the Enter button for 3s. Press the Enter button again, the display will show 'Pin Learn'. Press the down arrow until 'Network' is displayed. Press the Enter button again. The display will show 'DSL/FTP Mode'. Use the down arrow to step through until 'Tunnel Port 443' is displayed. Press the Enter button. \* will be displayed. Use down arrow to change to 10443.
- Once selected hold the Enter button down till 'Notice - Saved!' is displayed.

## DNS Addr 1

Required to convert host names that are used to contact the server.

## DNS Addr 1


Alternative DNS addresses e.g. 8.8.8.8 or 1.1.1.1.

Edit mode for that part of the menu can be exited at any time, without saving changes, by pressing  for 5s. This will return you to the sub-menu that you were making changes in.

The configuration menu can be exited at any time without saving any changes by pressing  for 5s. This will take you back to the scrolling status display.

### Web passcode

This code is used to set up both the installer and customer app, it can be changed from its default.



This passcode can be changed any time, if required, via this menu within settings.  
 For best practice, mobile app access requires the Installer to set up a Web passcode and pin in the device and then advise and show the end customer how to change the PIN.  
 Edit mode for that part of the menu can be exited at any time, without saving changes, by pressing  for 5s. This will return you to the sub-menu that you were making changes in.  
 The configuration menu can be exited at any time without saving any changes by pressing  for 5s. This will take you back to the scrolling status display.


### Serial connection panel type

This menu selects the panel connection type for serial connected panels (RS232 or RS485).


#### Settings:


- None
- Menvier
- Dimension GD 232 (Galaxy Dimension 48/96/264/520 (RS232 9600 8n1))
- Dimension GD 485 (Galaxy Dimension 48/96/264/520 (RS485))
- Galaxy G3 232 (G3 48/144/520 (RS232 9600 8n1))
- Galaxy G3 485 (G3 48/144/520 (RS485))
- Galaxy G2 485 (G212/20/44 (RS485))
- Galaxy Classic 485 L (Classic 8/18/60/128 (RS485))
- Galaxy Flex 485
- Galaxy Classic 485 H (Classic 500/504/512 (RS485))
- Texecom 816 (Texecom 412/816/832 (RS232 19200 8n2 inv))
- Texecom 48 88 (Texecom 48/88/168 Com – IP (RS232 19200 8n2 inv))
- Texecom Premier (Texecom Premier Elite 48 Com-IP (RS232 19200 8n2 inv))
- Bespoke Panel
- Pyronix (RS232 9600 8n1) (Europe only not UK)
- Contact IP (RS232 9600/2400/1200 8n1)
- Panel RS232 UDL (8n1)
- Contact IPv2
- Eaton I-ON

Example – changing the unit to connect to a Texecom Premier Elite panel via RS485:



- Access the configuration menu by holding the Enter button for 3s. Press the Enter button again, the display will show 'Pin Learn'. Press the down arrow until serial panel type is shown. Press the Enter button again to enter serial panel Type. Default status = None will be shown.
- Use the down arrow to step through the available panel. Once the desired Panel is reached press and hold the Enter button down till 'Notice – Saved!' is displayed.
- Then it will return to the same position in the menu for you to select a different panel or use the down arrow to step through all pins to get to the Back option.


Edit mode for that part of the menu can be exited at any time, without saving changes, by pressing  for 5s. This will return you to the sub-menu that you were making changes in.

The configuration menu can be exited at any time without saving any changes by pressing  for 5s. This will take you back to the scrolling status display.

## Diagnostics

### Web server

To allow access to program the unit via a laptop, the web server needs to be set to enabled. Access to the web server is then allowed.



You'll then need to plug in your laptop and log in to the device. Open your web browser and enter `http://192.168.222.222`.

You can get the username and password from your AddSecure account manager. The unit will now have a static IP address of 192.168.222.222 for the duration that the web console is enabled. To access the Web Server a PC needs to be connected to the Ethernet port. If an Ethernet switch is used to allow connectivity to the

customer's network and your laptop then the units will still be able to communicate with the platform over the IP path.

If you plug the cable directly from the PC to the unit, the unit will be unable to communicate across the IP path. A comms fault on the IP path will therefore be signalled to the ARC after the normal time out (normally 90 seconds for DP4, 3 minutes for DP3, 30 mins for DP2). The COMMS output will also operate after the time out (normally 3/30 mins) indicating single path fail. This is considered normal. The Mobile path will still function while the web server is enabled e.g. the unit responds to incoming polls over mobile.

- Web server will automatically exit after 20 minutes.
- Installer can disable the web server at any time.
- Web server will revert to disabled if the unit is restarted.
- To access the web server, a PC needs to be connected to the Ethernet port.
- Configure the PC to have a static IP address within the range 192.168.222.xxx.

E.g. set the PC to have the following static details:


- IP address = 192.168.222.10
- Subnet mask = 255.255.255.0
- Gateway = 192.168.222.222.


Access the configuration menu by holding Enter button for 3 seconds, press the Enter button again, the display will show Pin Learn. Press the down arrow until diagnostics is shown. Press the Enter button again to enter diagnostics. Web Server, Disabled is displayed. Press Enter button again, \* is displayed, press down arrow enabled is shown, hold Enter button to save changes.


### Offline reboot screen

Device will automatically reboot if offline for approx. 2 hours (time will vary between 2 and 3 hours)

This feature can be disabled as follows




You can exit Edit mode at any time, without saving changes, by pressing  for 5s. This will return you to the sub-menu that you were making changes in.


Exit configuration menu at any time without saving any changes by pressing  for 5s. This will take you back to the scrolling status display.

### Restore defaults

The Restore defaults option on the menu can be used to set the unit back to factory default. That is all settings will be reset to their standard values.

*Example – setting the unit back to factory default:*



The configuration menu can be exited at any time without saving any changes by pressing  for 5s. This will take you back to the scrolling status display.



# Web server


# Web server

Descriptions below are when directly connecting to the Ethernet port of the unit. The same menu options are available via the web portal or AddSecure installer app.

Log in with the AddSecure username = xxxxx,  
password = xxxxxxxx

This is available from the AddSecure Technical Helpdesk or your AddSecure account manager.

To comply with EN 50136-2 Clause 5.2 Access levels, the PIN code access must be set to 6-digits. You can change the access PINs in the user settings. This applies for all types of access to the device.



**LAN Sign in**

Enter your username:

Enter your password:

**Sign In**



The Webportal displays the license agreement and privacy agreements on first login and the user must accept the T&Cs before continuing. The date and time when the user accepts the license agreement is captured. The Installer should obtain the End Customers consent should they wish to use any personal information.


## The menu

The menu bar on the left hand side can take you to any of the menu options described below.

Should you need to make any changes in the following menu options click on Save. This will save your changes to the unit.

The box below will be shown when changes have been saved. Click OK to continue.





### Main status display

When you first log in you are presented with the main status page. You can return to this page at any time by clicking Main on the menu bar.

The status page shows the User operated outputs. Output 2 (FUNC), which can be renamed in the settings menu, can be operated by clicking on the interactive icon if output 2 (FUNC) is set up as User. When operated, the interactive icon turns orange from blue and back to blue when pressed again.

Output 3 (FIRE) can be operated in the same way when Output 3 (FIRE) is

set to User. If the Output Icon is grey it means that the Output is not set up as User operated.

In the example above Output 2 is not configured to be User operated. Output 3 is configured.

### Status

These icons show the status of the signalling paths and if there are any outstanding alarms. Green for the signalling path icons indicates signalling paths are successfully connected to the platform. Red indicates that a path is down.

In the example above LAN is red, (showing down), as we have connected the laptop into the Ethernet port – therefore the connection to the customer’s network is unplugged and the IP connection is in the down state.

The bell icon is red in the example above as we have a Pin 4 alarm, shown in the system messages box, which you would expect to see as the system will be open.


If no pin inputs are in alarm, the bell icon will be green.

### System messages


The system messages box will scroll through the key messages:

- Battery – will indicate if supply is low.
- Alarms GPI Cut – any pin inputs that are in the cut state (EOL or DEOL).
- Alarms GPI short – any pin inputs that are in the short state (DEOL).
- Alarms GPI – any pin inputs in alarm.
- Signal strength – signal strength in dBm and the name of the mobile network operator.


## WEBSERVER



Pin	Status	State
Pin 1	●	Short
Pin 2	●	OK
Pin 3	●	OK
Pin 4	●	Alarm
Pin 5	●	OK
Pin 6	●	OK
Pin 7	●	OK
Pin 8	●	Cut
Pin 9	●	OK
Pin 10	●	OK
Pin 11	●	OK
Pin 12	●	OK
Pin 13	●	OK
Pin 14	●	OK
Pin 15	●	OK
Pin 16	●	OK



Main
Pins
Events
Users
Settings
Logout



Time	Event	Type
2018-11-11 15:23:51	Tamper Alarm	Event
2018-11-11 15:23:51	GPI Alarm	Event
2018-11-11 15:23:51	Config Change	
2018-11-11 15:20:42	Access	Event


### Pins

Pins shows the Name (if changed) and status of each of the pin alarms. OK with a green dot shows the pin is not in alarm and Alarm with the red dot if in alarm. It will also show if a pin is in a cut or short state, with a blue dot and cut or short.

### Events

This shows the most recent events. If you click on the dropdown you are able to filter the events by type. e.g. Alarms, System, Configuration or Connection. In the event log on the app or on the unit web page \*\* indicates a non-reportable event. If a single \* is displayed by an event this indicates no acknowledgement has been received.

## WEBSERVER




### Users

This menu allows you to set up additional installers and end customer app access to the unit and change login PIN numbers.

To comply with EN 50136-2 Clause 5.2 Access levels, the PIN code access must be set to 6-digits. You can change the access PINs in the user settings. This applies for all types of access to the device.

For best practice, mobile app access requires the Installer to set up a Web passcode and pin in the device and then advise and show the end customer how to change the PIN.

For passcode/pin recovery the End Customer needs to contact their Installer. For PIN resets you can use the reset pin function in the Ultrasync portal.



### Settings

The Settings menu has sub-menus to be able to program the unit. The first screen gives you details of the device including MAC address and firmware version. Use the down button to step to the first sub-menu option or use the drop down to access the sub-menus.

## WEBSERVER

The screenshot shows the 'Settings Selector' interface with the 'Status' dropdown menu selected. Below the menu are 'Up', 'Down', and 'Save' buttons. The main content area is titled 'Ultra Sync' and contains several input fields: 'Status' (Online), 'IP Path' (Online), 'Mobile Path' (Online), 'IP Path' (IP Path), 'IP Status' (Connected), 'IP Media' (Ethernet), 'Mobile Path' (Mobile Path), 'Status' (Registered), 'Technology' (4G LTE), 'Signal Strength' (-102 dBm), 'Operator ID' (SIM1 23430).

**The Status sub-menu** shows the status of the IP path. It's offline and disconnected in the example shown on the left as we have the laptop plugged into the Ethernet port.

It also shows the mobile path status, if it's using 2G or 4G, the signal strength, which SIM and operator.

- 23410 – O2
- 23415 – Vodafone
- 23420 – Three
- 23430 – EE

The screenshot shows the 'Settings Selector' interface with the 'Network' dropdown menu selected. Below the menu are 'Up', 'Down', and 'Save' buttons. The main content area is titled 'Ethernet' and contains several input fields: 'Method' (DHCP), 'Tunnel Port' (443, 10443), 'Remote Access' (Web Access Passcode: 65790246).

The screenshot shows the 'Settings Selector' interface with the 'Network' dropdown menu selected. Below the menu are 'Up', 'Down', and 'Save' buttons. The main content area is titled 'Ethernet' and contains several input fields: 'Method' (Static), 'IP Address' (192.168.1.57), 'Subnet Mask' (255.255.255.0), 'Gateway' (192.168.100.1), 'DNS 1' (192.168.100.1), 'DNS 2' (0.0.0.0), 'Tunnel Port' (443).

**The Network sub-menu** allows you to change from DHCP to static and to alter the Web Access Passcode. To change to static click on the drop down arrow which will then show DHCP and Static. Click on static. Additional boxes will be displayed allowing you to add in the static IP, Subnet and Gateway addresses. Make your changes and then click the Save button. 'Program Success' will be displayed.

## WEBSERVER

Input

- Input 1
- Input 2
- Input 3
- Input 4
- Input 5
- Input 6
- Input 7
- Input 8
- Input 9
- Input 10
- Input 11
- Input 12
- Input 13
- Input 14
- Input 15
- Input 16

Low  
High

None  
EOL  
DEOL

Output 1

- BSIA Form 175
- Single Path Fault
- Dual Path Fault
- IP Path Fault

Output 2

- User
- Dual Path Fault
- Mobile Path Fault
- RPS
- Fire NAK
- Keyswitch

Output 3

Output Type 3

- User
- Fire ACK
- Keyswitch

In the **GPIO sub-menu**, by using the dropdown arrows on each section, you can change any of the pin input status from High (positive removed) to Low (positive removed).

Settings Selector

GPIO

Up Down Save

Input

Input 1

Input Sense 1

High

Input EOL 1

None

Mains Fail Time

7

Output

Output 1

Output Type 1

BSIA Form 175

You can set up either end of line (EOL) or dual end of line (DEOL) for each pin as required. Mains fail time for Pin 13 can be adjusted. If set to Zero, Pin 13 becomes a normal alarm pin. Each of the three Outputs can be configured as described earlier in this guide.

Settings Selector

GPIO

Up Down Save

Input

Input 8

Input Sense 8

High

Input EOL 8

DEOL

Mains Fail Time

7

Output

Output 2

Output Type 2

Fire NAK

In the example on the left, we show Pin 8 as Active High, with DEOL monitoring. Output 2 is set to operate as a FIRE NAK output (operates if an acknowledgement on a Pin 1 alarm is not received within 80 seconds).

Make all the changes to the Pin inputs and outputs then click the Save button to store your changes in the unit. 'Program Success' will be displayed.

## WEBSERVER

The screenshot shows the 'Settings Selector' interface for a Keyswitch. At the top, there is a purple header with the text 'Settings Selector'. Below it is a dropdown menu labeled 'Keyswitch'. Underneath are three buttons: 'Up', 'Down', and 'Save'. The main content area is titled 'Keyswitch' and contains several fields: a 'Name' text input, an 'Output Mode' dropdown menu (set to 'Momentary'), an 'Output Pulse Period (ms)' text input (set to '1000'), an 'Input Mode' dropdown menu (set to 'Pin Input'), an 'Input Pin' dropdown menu (set to 'Input 4'), and an 'Input Armed State' dropdown menu (set to 'Armed=Low, Disarmed=High').

This screenshot shows two sections of the web interface. The first section is titled 'Output Mode' and has two options: 'Momentary' (highlighted in blue) and 'Latched'. The second section is titled 'Input Mode' and has two options: 'Pin Input' (highlighted in blue) and 'Alarm'.


The screenshot shows the 'Settings Selector' interface for a Name Editor. At the top, there is a purple header with the text 'Settings Selector'. Below it is a dropdown menu labeled 'Name Editor'. Underneath are three buttons: 'Up', 'Down', and 'Save'. The main content area is titled 'Functions' and contains two text input fields: 'Output 2 (FUNC)' and 'Output 3 (FIRE)'. Below this is a section titled 'Pins' with four text input fields labeled 'Pin 1', 'Pin 2', 'Pin 3', and 'Pin 4'.

In the **Keyswitch sub**-menu, you can set up a keyswitch to operate in conjunction with the AddSecure App. Any pin can be used, but will typically be Pin 4. It can be Latched or Momentary and armed low or high. There is also the option to set up Keyswitch with extended format signalling.


If using the Keyswitch you will need to ensure the intrusion alarm system is set up to comply with the requirements of BS 8243 when implementing remote setting/unsetting via the app.

In the **Name Editor sub**-menu, you can add names to the pin inputs. This will then show up on the customer app and notifications. You can choose a description for the User relay outputs. Click Save when you have entered all the information.


## WEBSERVER



**The Panel sub-menu** allows selection of the Serial connection for specific panel types. Select the drop down next to Type and you will get a list of panel types. Select the required panel type and connection type and then click Save. 'Program success' will be displayed.




**The Reports sub-menu** allows you to set up a number of email addresses that could receive emails on the various options. E.g. Alarms and System messages.



**The Default sub-menu** gives you the option to disable the auto reboot. This is where the device will auto reboot to try to restore the connection after approximately two hours of losing that connection to the platform. Use the drop down arrow next to enabled, change to disabled and click save. This will stop the device auto rebooting.

Reboot device allows you to reboot the device remotely. Click reboot now. You will have to re-connect to the device as rebooting will lose the connection. Try reconnecting after a couple of minutes. To restore the unit to factory settings click Reset now.

## Logout



Clicking Logout will take you back to the sign in screen.

Should the web server enablement time out, you will not be able to save changes. You will need to re-enable the web server through the programming buttons.

## Firmware updates

During the installation process or annual maintenance visit, it's important to check to see if there are any firmware updates available for the device.

You should apply any firmware updates at that point – either from

the AddSecure web portal, or by the AddSecure Helpdesk under the instruction of an on-site engineer.

There'll be firmware updates for security updates, bug fixes and additional functions. Once you've installed a device, you can check for firmware updates and apply them at any time, using the AddSecure web portal.

It's your responsibility to update the firmware, as a reboot of the device will take place.

Notification of software updates is via the web portal. If the update is critical, then the installer will receive an email indicating the risks mitigated by the new version. The release notes and relevant documentation will also provide details on the period of service disruption should the user initiate the upgrade.

Relevant upgrade documentation is saved as part of the Webportal for the installers. You will need to login to find the latest information.

It is the responsibility of the installer to communicate with the end-customer before changes are made to the communicators.

## Web portal and AddSecure app

The device menus are accessible via the AddSecure web portal and app.

### AddSecure App Password

To change an existing known password on the AddSecure App

- Go to Settings and turn off the app lock (password) by toggling the button.
- You will need to enter your current password,
- When you re enable app Lock (password) it will ask you to create a new password.
- If you forget your App password you will need to un install and re install the app.

When using the web portal and app remotely after installation is completed then the following will apply.

## Compliance with the user access level requirements of EN 50136

Access to the configuration options by an installer must be authorised by a level 2 user e.g. site owner. For the Next Generation alarm transmission equipment, compliance is achieved at installation by requiring a one-time authorisation agreed as part of a service level agreement.

It's recommended the signed authorisation is retained with the 'as fitted' documentation.

An example authorisation form is provided in the Appendix.



# Interconnection monitoring

# Interconnection monitoring

If the enclosure housing the unit is not next to, or close coupled to, the fire panel, e.g. right next to the fire panel enclosure or perhaps a very short (<25mm/1") section of cable conduit coupling the enclosures together, then there is a requirement in EN54-21 to detect open or short circuits on the interconnection wiring between the fire panel and the unit, as well as an indication back to the fire panel of an issue.


The power connections need to meet EN54-21 7.5.2 when the unit is fitted in an enclosure remote from the Fire control panel.

To enable the interconnection monitoring you will need to program the unit via the config menu, app, laptop or web portal.



## Wiring for interconnection monitoring

Each of the pins required will need to be wired as shown below.



**You will need 1 x 3K3 and 1 x 10K resistors for each pin with DEOL interconnection monitoring.**

3.3KΩ 1%



orange, orange, black, brown, brown

10KΩ 1%



brown, black, black, red, brown

### What happens when pins are configured and wired in this way

The dual resistor EOL mode is able to detect four states.

- Alarm event
- Restore
- Wire cut
- Wire shorted

The OLED display will show pin cut 1 through 16 to indicate the wire cut condition for any of Pins 1–16, which are presently in the wire cut state.

**Alarms GPI Cut  
6**

Above, example Cut on Pin 5.

The OLED display will show Short 1 through 16 to indicate the wire shorted condition for any of Pins 1–16, which are presently in the wire shorted state.

**Alarms GPI Short  
8**

Above, example Short on Pin 8.

### Example configuration and wiring for connection to fire panel with interconnection monitoring

Ensure that the required pins have Dual EOL enabled in the config menu. In the example Pin 1 and Pin 8 have been enabled for this. Note it is available on Pins 1 – 16

- Output 1 = Single path fail
- Output 2 = Fire NAK
- Output 3 = Fire ACK




Figure 8 – Typical fire alarm connections for panel with two inputs and unit with interconnection monitoring

### Roaming SIMs

The unit has two SIMs.

- SIM 1 – EE network sim with 4G and 2G.
- SIM 2 – a UK roaming sim with 4G and 2G network access.

The unit uses smart roaming to determine which network to use.

Should network connectivity be lost the unit will try different networks, 4G and 2G and will also swap SIMs if required.

Should the unit lose connectivity with the AddSecure platforms, or lose registration with the current base station, then the unit will roam onto the next available 4G or 2G network.

### Panel upload Download and Enhanced format signalling (SIA/CID)

Remote access to the alarm panel can be achieved using the AddSecure UDL facility. Additional panel set up information is also available for enhanced format signalling. Contact your AddSecure representative for further details.

### Dial Capture

The Dial Capture pins present a 'phone line' to the panel's onboard digital communicator. Connect the alarm panel's digital communicator line connections to the terminals marked DIAL CAP on the unit.

The terminals are not polarity conscious.

Configure the alarm panel digital communicator to dial 29 and use the last 4 digits of the TAID as the account number.

The Dial Capture board will auto detect the panel protocol as events are sent from the alarm panel. SIA, CID or FF.

Please check current panel compatibility listing.

If there are any issues you can easily spot them and put them right by connecting a test phone, or listening device to the Dial Capture inputs. The Dial Capture pins with a test phone connected and line seized (as if making a phone call) will provide a continuous tone (dialling tone). The Dial Capture pins will also have a voltage on there of 45V.

### Serial panel connections

Select the required panel via the serial panel type menu option via the buttons, app or web portal.

Please contact your AddSecure representative for the latest information on panel compatibility for Upload Download and enhanced format signalling via serial connections.

Then wire in the panel using the GND, TX/B and RX/A terminals.

Example below shows connection via RS 485 to a Galaxy Dimension panel:




Figure 9 (not to scale).

### Connection advice

The unit should be connected to the Honeywell Galaxy panel as shown in figure 9, RS485A to A1 and RS485B to B1. Do not use the secondary data line (if your panel has one – A2/ B2) as it will not work. Ensure that the GND of the unit is connected to the GND terminal on the panel.

It is recommended that good quality screened cable (Belden type, CAT5e or equivalent) is used in all wiring of this type to avoid interference on the panel's data bus. A 680Ω resistor should be used at the end of the 'daisy chain' line of devices in the normal way, taking care not to exceed the maximum number of devices allowed on that data line. If the unit is fitted less than 5m from the alarm panel then an additional termination resistor is generally not required.

The unit does not have a terminating resistor.

## Alarm list

Description	Pin	CID (zone)
Inputs 1–16	1–16	323 (901–16)
Low Battery	985	302 (999)
Unit reboot	984	305 (995)
Panel dial fail	983	314 (999)
Software changed	979	304 (999)
Panel message error	958	311 (997)
Panel Connection (RS485)	n/a	356 (997)
BSIA 175 Test	n/a	354 (998/999)
Inputs 1–16 cut alarm	n/a	325 (901–16)
Inputs 1–16 Short Alarm	n/a	324 (901–16)
IP Path	1023	351 (999)
Mobile Path	1022	351 (998)
Total Comms Fault	n/a	350 (999)

Figure 10 – Alarms signals as delivered to your ARC

**IMPORTANT NOTE:** If intending to use Dial Capture or serial for sending alarms, please confirm beforehand with your ARC that their automation software is capable of differentiating correctly between pin alarms (NGP Advanced, NGP Advanced Extra, NGP Advanced Extra DP4 or AddSecure Platform generated alarms) and alarm panel generated ZONE alarms.

### IP specification notes

IP Protocol: TCP  
Port: 443 or 10443

### Data Usage/requirements

IP polling is every 30 seconds. A poll and response results in 288 total bytes transferred (including IP headers). A small number of alarms will also typically be generated per day and these result in 296 bytes transferred. Overall this generates approximately 800K bytes per day, per site.

### Traffic direction

The NGP Advanced, NGP Advanced and NGP Advanced Extra DP4. Extra establishes an outgoing TCP connection from your network to the AddSecure platform. Once this outgoing TCP connection has been established, traffic over that connection is 2-way.

### Additional protocols

Only TCP is required from your network.

### Port forwarding

No ports need to be forwarded in the incoming direction. The outgoing TCP connection connects to port 443 or 10443 on the AddSecure network, so you would need to allow outgoing access to port 443 or 10443 if you block that by default.

### NAT

Not required.

### 4G/2G requirements


You do not need to route mobile traffic. The mobile connection from the communicator through to the AddSecure platform and on to the ARC is entirely independent of your network.

### DHCP and static addressing

The communicators can be configured as either DHCP clients or with specific static IP addresses on your internal network as you prefer.

### DNS server

The device uses host names for establishing connection to the servers so DNS addresses will be required.



# Personal Data

## Personal information consent

Installers should obtain the End Customers consent should they wish to include any personal data in the app or portal.

## End of Service

The End Customer needs to follow the standard process to cease the service with their installers. The following steps should be followed by the installer when disabling a service. The Installer should cease the service with the Alarm Receiving Centre. AddSecure will then cease the entry on the portal within 3 months (this allows for re instatement of any cease in errors). **The communicator needs to be recovered from site by the installer or defaulted to restore its configuration to factory defaults.** The installation quick start guide provides steps to set the unit back to factory defaults. The unit should then be powered down so that it will not attempt connection to the network.

All personal data associated with the unit will be deleted from the device. However, historical event information will remain in the system archives for 7 years as part of compliance requirements.

## Withdraw of End Customer Consent

The only way for an End Customer to withdraw consent of personal data processing by AddSecure is to deactivate the service. Please refer to the End of Service section above for more details. The End Customer will need to remove the APP from their personal smart device using standard methods. Installers will need to delete the Site from their APP using standard site deletion method.

AddSecure privacy policy can be found here <https://www.addsecure.com/alarm-signalling/uk/> which includes what to do if you are unhappy about how we have handled personal information.



# Disposal

The symbol shown here and on the product means that it's classed as Electrical or Electronic Equipment, and should not be disposed of with other household or commercial waste at the end of its working life.

The Waste Electrical and Electronic Equipment (WEEE) Directive (2002/96/EC) has been put in place to recycle products using the best available recovery and recycling techniques, to minimise the impact on the environment, treat any hazardous substances and avoid increasing landfill.



## Product disposal instructions for users

Please dispose of the product as per your local authority's recycling processes. For more information please contact your local authority or retailer where the product was purchased.

You can return the product to the freepost address using the Royal Mail returns at [www.royalmail.com/track-my-return](http://www.royalmail.com/track-my-return)

## AddSecure Returns

**C/O GXO**

**Gate 3 Harding Road**

**Brinklow**

**Milton Keynes**

**MK10 0EE**

## Disclaimer

The manufacturer or his agents disclaim responsibility for any damage, financial loss or injury caused to any equipment, property or persons resulting from any use of this equipment. The manufacturer is not liable for any purely economic loss arising from any use of this equipment. All responsibility and liability in the use of AddSecure products are assumed by the user.

This unit is designed to be used in customer premises. Use of this equipment in other locations may void warranty.

This unit is not intended for use in marine environments or water borne vessels.

AddSecure may make changes to features and specifications at any time without prior notification in the interest of ongoing product development and improvement.

# Glossary

**ADSL**

Asymmetric digital subscriber line (Broadband)

**ARC**

Alarm Receiving Centre

**BSIA**

British Security Industry Association

**CSQ**

Carrier Signal Quality (RSSI,BER)

**DHCP**

Dynamic Host Configuration Protocol

**DNS**

Domain Name Server

**F175**

Form 175 as issued by BSIA

**GMT**

Greenwich Mean Time

**IP**

Internet Protocol

**LAN**

Local Area Network

**MMCX**

Micro Miniature Coaxial Connector

**OLED**

Organic Light Emitting Diode

**RSSI**

Received Signal Strength Indicator

**RPS**

Return Path Signalling (An output that confirms delivery of Pin 4 to the ARC)

**RX**

Receive

**SID**

Serial Identity number – 12 digit unique identity number of a unit

**SIM**

Subscriber Identity Module (sim card)

**TTL**

Transistor Transistor Logic

**TX**

Transmit



# Approvals

**AddSecure Ltd.**  
**Wyvols Court**  
**Swallowfield**  
**Reading**  
**RG7 1WY**

March 2026

Compliance to EN 50136-2: 2013 and EN 50131-10: 2014  
 EN50136, EN50131, PD6669, PD6662

NGP Advanced is suitable for use in systems installed to conform to PD 6662:2017 at Grade 2/3 (DP2) and environmental class 2.

NGP Advanced Extra is suitable for use in systems installed to conform to PD 6662:2017 at Grade 3 (DP3) and environmental class 2.

NGP Advanced Extra DP4 is suitable for use in systems installed to conform to PD 6662:2017 at Grade 4 (DP4) and environmental class 2.'



**Technical Data:** see [www.addsecure.com/alarm-signalling/uk/](http://www.addsecure.com/alarm-signalling/uk/)

**Technical support:**

AddSecure Ltd  
 Phone: +44 20 461 431 70  
 Email: [support.smartalarms.uk@addsecure.com](mailto:support.smartalarms.uk@addsecure.com)

**Support**

For assistance with your AddSecure installation, please contact the AddSecure Helpdesk on: +44 20 461 431 70

If there is a problem with the service and/or communicator the End Customer should contact the alarm installer. The alarm installer can contact AddSecure Helpdesk M-F 9 till 5.

Description	Transmission Time	Information Security	Substitution Security	Reporting Time
NGP Advanced	DP4	DP4	DP4	DP2
NGP Advanced Extra	DP4	DP4	DP4	DP3
NGP Advanced Extra DP4	DP4	DP4	DP4	DP4

## APPROVALS

EN 54-21:2006

Alarm transmission and fault warning routing equipment for fire alarm systems.

Constasy of performance certificate for Construction Products Regulation.

2831-CPR-F5029

0832-UKCA-CPR-F1945

NGP Advanced, NGP Advanced Extra and NGP Advanced Extra DP4



**AddSecure Ltd.**

**Wyvols Court**

**Swallowfield**

**Reading**

**RG7 1WY**

Description	Fire Product	Transmission time Classification	Transmission time Max. Values	Reporting time Classification	Substitution Security	Information Security	Network Availability
<b>NGP Advanced</b>	EN 54-21 Type 1	D4	M4	T3	S2	13	A4
<b>NGP Advanced Extra</b>	EN 54-21 Type 1	D4	M4	T4	S2	13	A4
<b>NGP Advanced Extra DP4</b>	EN 54-21 Type 1	D4	M4	T5	S2	13	A4

Technical Data: see [www.addsecure.com/alarm-signalling/uk/](http://www.addsecure.com/alarm-signalling/uk/)




**KM 825964**

In respect of: Internet of Things (IoT)  
Security of a device against common vulnerabilities for use in a commercial environment (includes Residential environment)



**KM 825963**

In respect of: OWASP ASVS and MASVS  
Secure Digital Applications  
Mobile Applications (OWASP MASVS Ver 1.3 Level 1):  
Web Application (OWASP ASVS 4.0.2 Level 1)  
The AddSecure Ultrasync Portal Application



### LPCB certification

- Extensive testing by BRE has independently validated the performance of NGP Advanced/NGP Advanced Extra/NGP Advanced Extra DP4 and demonstrated compliance with the applicable EN 50131 and EN 50136 standards.
- Regular on-going surveillance of the manufacturing facilities by BRE, ensures the high quality of the Next Generation range is maintained through the life of the products.
- LPCB certification provides prescribers and owners of intrusion alarm systems with assurance that the signalling equipment will respond rapidly and continue function reliably, a prerequisite for any monitored alarm system.

### BSI 'Kitemark' accreditation for IoT devices, app and portal

- The Kitemark is designed to help consumers confidently and easily identify IoT devices, apps and portals that they can trust to be safe, secure, and functional.
- Once the BSI Kitemark is achieved the product will undergo regular monitoring and assessment including functional and interoperability testing, further penetration testing and an audit to review any necessary remedial action. Importantly, if security levels and product quality are not maintained the BSI Kitemark will be revoked until any flaws are rectified.
- The IoT Kitemark assessment process involves a series of tests that help ensure the device is fully compliant to the requirements.

Before being awarded the Kitemark the manufacturer is assessed against ISO 9001, and the product is required to pass both an assessment of functionality and interoperability, as well as penetration testing scanning for vulnerabilities and security flaws.

- An app that has been awarded a BSI Kitemark™ for Secure Digital Applications has demonstrated that it has appropriate robust security controls in place for the information it is handling. To achieve the BSI Kitemark, an app must undergo rigorous and independent testing.

### Police CPI 'Secured By Design' (SBD) accreditation

- Police Crime Prevention Initiatives (Police CPI) is a police-owned organisation which delivers a wide range of crime prevention and demand reduction initiatives across the UK.
- The extensive Police CPI portfolio covers a variety of crime prevention initiatives, of which Secured by Design is the most well-known, with all initiatives designed to keep the public safe from crime.
- Secured by Design (SBD) operates an accreditation scheme on behalf of the UK Police Service for products or services that have met recognised security standards. These products or services, which must be capable of deterring or preventing crime, are known as being of a 'Police Preferred Specification'.

# Appendix

## Example authorisation form

For the purposes of on-going maintenance and configuration

*Company name*

Authorises

*Installer company name*

Remote access to AddSecure Next Generation Supervised Premises Transceiver

**Serial No.** *number*

**Installed at:** *premises address*

*Date*

*Signature*

**AddSecure Limited**  
**Registered in England and Wales**  
**Company Number:** 03593453  
**Registered Office:** 5th Floor, R+ Building, 2 Blagrave Street,  
Reading, United Kingdom, RG1 1AZ  
**Phone:** +44 (0)20 4614 3170  
**Email:** [info@addsecure.com](mailto:info@addsecure.com)  
**Website:** [addsecure.com](http://addsecure.com)

**ADD:SECURE**